














LAY5 Push-button Switch and Indicator Light

Button Switch












	Elucidation	Color	Contact type		Reference	Weight (kg)	Size
			NO	NC			
 LAY5-BA..	Flat push-button	White	1	-	LAY5-BA11	0.0560	
		Black	1	-	LAY5-BA21	0.0560	
		Green	1	-	LAY5-BA31	0.0560	
		Yellow	1	-	LAY5-BA51	0.0560	
		Blue	1	-	LAY5-BA61	0.0560	
		Black	-	1	LAY5-BA22	0.0580	
		Red	-	1	LAY5-BA42	0.0580	
		Green	1	1	LAY5-BA35	0.0694	
		Red	1	1	LAY5-BA45	0.0694	
 LAY5-BL..	Extended button	Black	1	-	LAY5-BL21	0.0596	
		Green	1	-	LAY5-BL31	0.0596	
		Yellow	1	-	LAY5-BL51	0.0596	
		Blue	1	-	LAY5-BL61	0.0596	
		Black	-	1	LAY5-BL22	0.0600	
		Red	-	1	LAY5-BL42	0.0600	
		Green	1	1	LAY5-BL35	0.0731	
		Red	1	1	LAY5-BL45	0.0731	
		 LAY5-BP..	Button with waterproof button	Black	1	-	
Green	1			-	LAY5-BP31	0.0572	
Yellow	1			-	LAY5-BP51	0.0572	
Blue	1			-	LAY5-BP61	0.0572	
Red	-			1	LAY5-BP42	0.0592	
Green	1			1	LAY5-BP35	0.0706	
Red	1			1	LAY5-BP45	0.0706	

Take the spring coil button of function sign • button stop

 LAY5-BA..	Flat push-button with mark		1	-	LAY5-BA3311	0.0589	
			1	-	LAY5-BA3341	0.0589	
			1	-	LAY5-BA3351	0.0589	
			-	1	LAY5-BA4322	0.0590	
			-	1	LAY5-BA4342	0.0590	
			1	1	LAY5-BA4325	0.0721	
			1	1	LAY5-BA4345	0.0721	
 LAY5-BZ..	Self-clock button	Red	-	1	LAY5-BZ42	0.0710	
		Green	-	1	LAY5-BZ31	0.0710	
		Yellow	1	1	LAY5-BZ51	0.0710	
		Black	1	-	LAY5-BZ21	0.0710	
		Blue	1	-	LAY5-BZ61	0.0710	

LAY5 Push-button Switch and Indicator Light






"Urgent stop" of the lock button up type mushroom head button

	Elucidation	Color	Contact type		Reference	Weight (kg)	Size
			NO	NC			
 LAY5-BC..	Φ40mm Mushroom head button	Black	1	-	LAY5-BC21	0.0774	
		Green	1	-	LAY5-BC31	0.0774	
		Yellow	1	-	LAY5-BC51	0.0774	
		Blue	1	-	LAY5-BC61	0.0774	
		Red	-	1	LAY5-BC42	0.0774	
		Green	1	1	LAY5-BC35	0.0908	
		Red	1	1	LAY5-BC45	0.0908	
		 LAY5-BR..	Φ60mm Mushroom head button	Black	1	-	
Green	1			-	LAY5-BR31	0.0901	
Red	-			1	LAY5-BR42	0.0901	
Green	1			1	LAY5-BR35	0.0985	
 LAY5-BT..	Push-pull button	Φ40	-	1	LAY5-BT42	0.1180	
		Φ40	1	1	LAY5-BT45	0.1180	
		Φ60	-	1	LAY5-BX42	0.1810	
		Φ60	1	1	LAY5-BX45	0.0440	
 LAY5-BS..	Emergency stop push button	Φ30	-	1	LAY5-BS442	0.0767	
		Φ30	1	1	LAY5-BS445	0.0781	
 LAY5-BS..	Emergency stop push button with key	Black Φ40	1	-	LAY5-BS521	0.0800	
		Green Φ40	1	-	LAY5-BS531	0.0800	
		Red Φ40	-	1	LAY5-BS542	0.0935	
		Red Φ40	1	1	LAY5-BS545	0.0935	
 LAY5-BS..	Emergency stop push button with key	Black Φ60	1	-	LAY5-BS621	0.0910	
		Green Φ60	1	-	LAY5-BS631	0.0910	
		Red Φ60	-	1	LAY5-BS642	0.0910	
		Red Φ60	1	1	LAY5-BS645	0.1030	
		Φ40	-	1	LAY5-BS142	0.1097	
Φ40	1	1	LAY5-BS145	0.1235			
Φ40	1	1	LAY5-BS9445	0.1235			





Industrial equipment and switches

LAY5 Push-button Switch and Indicator Light

Choice switch

Elucidation	Color	Contact type		Reference	Weight (kg)	Size
		NO	NC			
 LAY5-BD..	V	1	-	LAY5-BD21	0.0669	
		1	1	LAY5-BD25	0.0803	
	∩	1	-	LAY5-BD41	0.0669	
		1	1	LAY5-BD45	0.0803	
		2	-	LAY5-BD33	0.0826	
∩	2	-	LAY5-BD53	0.0826		
	2	-	LAY5-BD73	0.0826		
	 LAY5-BJ..	V	1	-	LAY5-BJ21	0.0701
1			1	LAY5-BJ25	0.0835	
∩		1	-	LAY5-BJ41	0.0701	
		1	1	LAY5-BJ45	0.0835	
		2	-	LAY5-BJ33	0.0832	
∩	2	-	LAY5-BJ53	0.0832		
	2	-	LAY5-BJ73	0.0832		
 LAY5-BG..	V	1	-	LAY5-BG21	0.0925	
		1	1	LAY5-BG25	0.1090	
	∩	1	-	LAY5-BG41	0.0925	
		1	1	LAY5-BG45	0.1090	
		1	1	LAY5-BG61	0.0925	
∩	1	1	LAY5-BG65	0.1090		
	2	-	LAY5-BG33	0.1090		
	2	-	LAY5-BG53	0.1090		
	2	-	LAY5-BG03	0.1090		
∩	2	-	LAY5-BG73	0.1090		



The word lords make switch

 LAY5-B2-PA..	Locked	2	-	LAY5-B2-PA12	0.0467	
	Spring return	2	-	LAY5-B2-PA22	0.0467	
 LAY5-B2-PA..	Locked	2	2	LAY5-B2-PA14	0.0525	
	Spring return	2	2	LAY5-B2-PA24	0.0525	
 LAY5-C402	A-B	4	-	LAY5-C402	0.193	
		4	-	LAY5-C4022	0.193	
		2	-	LAY5-C201	0.190	
		2	-	LAY5-C2011	0.190	







Industrial equipment and switches

LAY5 Push-button Switch and Indicator Light





Choice switch with light

Elucidation	Color	Contact type		Reference	Weight (kg)	Size
		NO	NC			
 LAY5-BK..	Green	1	1	LAY5-BK2365	0.0907	
	Red	1	1	LAY5-BK2465	0.0907	
	Yellow	1	1	LAY5-BK2565	0.0907	
	Blue	1	1	LAY5-BK2665	0.0907	
	Clean	1	1	LAY5-BK2765	0.0907	

Take the light shine push button switch





 LAY5-BW..	The direct type	White	1	-	LAY5-BW3161	0.0769	
		Green	1	-	LAY5-BW3361	0.0799	
		Red	-	1	LAY5-BW3462	0.0769	
		Yellow	1	-	LAY5-BW3561	0.0769	
		Blue	1	-	LAY5-BW3661	0.0769	
 LAY5-BW..	RC type	White	1	-	LAY5-BW3171	0.0832	
		Green	1	-	LAY5-BW3371	0.0832	
		Red	-	1	LAY5-BW3472	0.0832	
		Yellow	1	-	LAY5-BW3571	0.0832	
		Blue	1	-	LAY5-BW3671	0.0382	
 LAY5-BZ..	Lamp stop	White	1	-	LAY5-BZ3161	0.0982	
		Green	1	-	LAY5-BZ3361	0.0982	
		Red	-	1	LAY5-BZ3462	0.0982	
		Yellow	1	-	LAY5-BZ3561	0.0982	
		Blue	1	-	LAY5-BZ3661	0.0982	

Double key button switch







 LAY5-BL..	Double key button switch	Green/Red	1	1	LAY5-BL8325	0.0721	
		Red/White	1	1	LAY5-BL8425	0.0721	
 LAY5-BW..	Double key square the head take a button a switch	Green/Red	1	1	LAY5-BW8365	0.0986	
		Red/White	1	1	LAY5-BW8465	0.0986	

LAY5 Push-button Switch and Indicator Light

The button touch some mold piece



Image	Elucidation	Color	Contact type		Reference	Weight (kg)	Size
			NO	NC			
	Spread to help/can act for of touch a point spiral press to carry son into the type		1	-	LAY5-BE101		
			-	1	LAY5-BE102		
	Take 1/2 touch some mold piece of the base used for button and 2 choice switch and key switch		1	-	LAY5-BZ101		
			-	1	LAY5-BZ102		
			2	-	LAY5-BZ103		
			-	2	LAY5-BZ104		
			1	1	LAY5-BZ105		

The spring coil reset a button









Image	Elucidation	Color	Contact type	Reference	Weight (kg)	Size	
							NO
	Flat push button	White	1	-	LAY5-EA11	0.0296	
		Black	1	-	LAY5-EA21	0.0296	
		Green	1	-	LAY5-EA31	0.0296	
		Yellow	1	-	LAY5-EA51	0.0296	
		Blue	1	-	LAY5-EA61	0.0296	
		Black	-	1	LAY5-EA22	0.0300	
		Red	-	1	LAY5-EA42	0.0300	
		Red	1	1	LAY5-EA45	0.0430	
	Extended push button	Black	1	-	LAY5-EL21	0.0326	
		Green	1	-	LAY5-EL31	0.0326	
		Yellow	1	-	LAY5-EL51	0.0326	
		Blue	1	-	LAY5-EL61	0.0326	
		Black	-	1	LAY5-EL22	0.0334	
		Red	-	1	LAY5-EL42	0.0334	
		Green	1	1	LAY5-EL35	0.0435	
		Red	1	1	LAY5-EL45	0.0435	
	Push button with waterproof	Black	1	-	LAY5-EP21	0.0313	
		Green	1	-	LAY5-EP31	0.0313	
		Yellow	1	-	LAY5-EP51	0.0313	
		Blue	1	-	LAY5-EP61	0.0313	
		Red	-	1	LAY5-EP42	0.0316	
		Green	1	1	LAY5-EP35	0.0316	
		Red	1	1	LAY5-EP45	0.0451	

LAY5 Push-button Switch and Indicator Light

Take the spring coil button of function sign





Image	Elucidation	Color	Contact type		Reference	Weight (kg)	Size
			NO	NC			
	Flat push button with mark	Green	1	-	LAY5-EA3311	0.0312	
		White	1	-	LAY5-EA3341	0.0312	
		Black	1	-	LAY5-EA3351	0.0312	
		Red	-	1	LAY5-EA4322	0.0317	
		Red	-	1	LAY5-EA4342	0.0317	
		Red	1	1	LAY5-EA4325	0.0449	
		Red	1	1	LAY5-EA4345	0.0449	

Nasty stop a mushroom button





Image	Elucidation	Color	Contact type	Reference	Weight (kg)	Size	
							NO
	Φ40mm Mushroom head button	Black	1	-	LAY5-EC21	0.0500	
		Green	1	-	LAY5-EC31	0.0500	
		Yellow	1	-	LAY5-EC51	0.0500	
		Blue	1	-	LAY5-EC61	0.0500	
		Red	-	1	LAY5-EC42	0.0505	
		Green	1	1	LAY5-EC35	0.0641	
		Red	1	1	LAY5-EC45	0.0641	
	Φ60mm Mushroom head button	Black	1	-	LAY5-ER21	0.0600	
		Red	-	1	LAY5-ER42	0.0600	
		Black	1	1	LAY5-ER25	0.0735	
		Red	1	1	LAY5-ER45	0.0735	
	Emergency stop switch	Φ30	-	1	LAY5-ES442	0.0500	
		Φ40	-	1	LAY5-ES542	0.0524	
		Φ40	1	1	LAY5-ES545	0.0745	
		Φ60	-	1	LAY5-ES642	0.0608	
		Φ60	1	1	LAY5-ES645	0.0745	
	Emergency stop switch with key	Φ40	-	1	LAY5-ES142	0.0800	
		Φ40	1	1	LAY5-ES145	0.0912	

LAY5 Push-button Switch and Indicator Light

Choice type switch





	Elucidation	Color	Contact type		Reference	Weight (kg)	Size
			NO	NC			
 LAY5-ED..	2 position maintain	[Symbol]	1	-	LAY5-ED21	0.0383	
			1	1	LAY5-ED25	0.0520	
	2 position self-return	[Symbol]	1	-	LAY5-ED41	0.0383	
			1	1	LAY5-ED45	0.0520	
	3 position maintain	[Symbol]	2	-	LAY5-ED33	0.0511	
	3 position self-return	[Symbol]	2	-	LAY5-ED53	0.0511	
 LAY5-EG..	2 position maintain key switch	[Symbol]	1	-	LAY5-EG21	0.0599	
			1	1	LAY5-EG25	0.0731	
			1	1	LAY5-EG41	0.0599	
	[Symbol]	[Symbol]	1	-	LAY5-EG45	0.0731	
			1	-	LAY5-EG61	0.0599	
			1	1	LAY5-EG65	0.0731	
	3 position maintain key switch	[Symbol]	2	-	LAY5-EG33	0.0727	
			2	-	LAY5-EG53	0.0727	
			2	-	LAY5-EG03	0.0727	
	[Symbol]	2	-	LAY5-EG73	0.0727		

The crew cut take a light button (the spring coil return)



 LAY5-EW..	Direct	[Symbol]	Green	1	-	LAY5-EW3361	0.0583	
			Red	-	1	LAY5-EW3462	0.0527	
			Yellow	1	-	LAY5-EW3561	0.0583	
			Blue	1	-	LAY5-EW3661	0.0583	
	RC type	[Symbol]	Green	1	-	LAY5-EW3371	0.0583	
			Red	1	-	LAY5-EW3471	0.0583	
			Yellow	1	-	LAY5-EW3571	0.0583	
			Blue	1	-	LAY5-EW3671	0.0583	
 LAY5-EV..	Direct	[Symbol]	Green			LAY5-EV63	0.0616	
			Red			LAY5-EV64	0.0388	
			Yellow			LAY5-EV65	0.0388	
			Blue			LAY5-EV66	0.0388	
			RC type	[Symbol]	Green			
	Red				LAY5-EV74	0.0750		
	Yellow				LAY5-EV75	0.0750		
	Blue				LAY5-EV76	0.0750		

LAY5 Push-button Switch and Indicator Light


Double key button switch

	Elucidation	Color	Contact type		Reference	Weight (kg)	Size		
			NO	NC					
 LAY5-EL8..	Double key button switch	IP40 [Symbol]	1	-	LAY5-EL8325	0.0485			
			1	1	LAY5-EL8425	0.0497			
	 LAY5-EW8..	Direct Double key square head take a light button resistance type	IP40 [Symbol]	1	-	LAY5-EW8465		0.0485	
1				1	LAY5-EW8365	0.0497			

The button touch some mold piece



 LAY5-EZ..	Take 1/2 touch some mold piece of the base used for button and 2 choice switch and key switch	1	-	LAY5-EZ101	0.0340	
		-	1	LAY5-EZ102	0.0346	
		2	-	LAY5-EZ103	0.0476	
		-	2	LAY5-EZ104	0.0478	
		1	1	LAY5-EZ105	0.0424	

The spring coil reset a button


 LAY5-EA..	The spring coil return type	Black	1	-	LAY5-EA121	0.0170	
			1	1	LAY5-EA125	0.0290	
		Green	1	-	LAY5-EA131	0.0170	
			1	1	LAY5-EA135	0.0290	
		Red	-	1	LAY5-EA142	0.0170	
		Blue	1	-	LAY5-EA151	0.0170	
			1	-	LAY5-EA161	0.0170	

LAY5 Push-button Switch and Indicator Light


Button switch box

	Type	Configuration	Mark
	LAY5-B101H29	Green flat button, 1NO	Sign mark: START
	LAY5-B102	Green flat button, 1NO	Switch mark: I
	LAY5-B103	Green flat button, 1NO	Switch mark: START
	LAY5-B111H29	Red flat button, 1NC	Sign mark: STOP
	LAY5-B112	Red flat button, 1NC	Switch mark: ○
	LAY5-J174	Red $\Phi 40$ mushroom auto-locking, turn	
		LAY5-B211H29	Green flat button, 1NO; Red flat button, 1NO
LAY5-B213		Green flat button, 1NO; Red flat button, 1NO	Switch mark: I ○
LAY5-B215		Green flat button, 1NO; Red flat button, 1NO	Switch mark: START, STOP
LAY5-B222		White flat button, 1NO; Black flat button, 1NO	Sign mark: ↑ ↓
	LAY5-B341H29	Green flat button, 1NO; Red flat button, 1NC; Green flat button, 1NO	Switch mark: FORWRD, STOR, REVERSE
	LAY5-B339	Green flat button, 1NO; Red flat button, 1NC; Green flat button, 1NO	Switch mark: OPEN, STOP, CLOSE
	LAY5-B324	Green flat button, 1NO; Red flat button, 1NC; Black flat button, 1NO	Switch mark: I ○ II
	LAY5-B334	White flat button, 1NO; Red flat button, 1NC; Black flat button, 1NO	Switch mark: ↑ ○ ↓
	LAY5-B311H29	White flat button, 1NO; Red flat button, 1NC; Black flat button, 1NO	Switch mark: → ○ ←


LAY5 Push-button Switch and Indicator Light




BS216



BS230



BS211




Button box for single hole
IP40
 $\phi 22, \phi 25$

LAY5-BOX1



Button box for two holes
IP40
 $\phi 22, \phi 25$

LAY5-BOX2



Button box for three holes
IP40
 $\phi 22, \phi 25$

LAY5-BOX3



Button box for four holes
IP40
 $\phi 22, \phi 25$

LAY5-BOX4




Button box for five holes
IP40
 $\phi 22, \phi 25$

LAY5-BOX5




Button box for six holes
IP40
 $\phi 22, \phi 25$

LAY5-BOX6



Button box for single hole
IP40/54
 $\phi 22, \phi 25$

LAY5-BP01



Button box for two holes
IP40/54
 $\phi 22, \phi 25$

LAY5-BP02



Button box for three holes
IP40/54
 $\phi 22, \phi 25$

LAY5-BP03



Button box for five holes
IP40/54
 $\phi 22, \phi 25$

LAY5-BP05



Button box for six holes
IP40/54
 $\phi 22, \phi 25$

LAY5-BP06



Button box for four holes
IP40/54
 $\phi 22, \phi 25$

LAY5-BP04