## YCB6H-63

Miniature Circuit Breaker OPERATION INSTRUCTION Standard: IEC 60898-1



Before installing and using this product, please read this manual carefully and pay more attention to safety.

# YCB6H-63 series

# Miniature Circuit Breaker Instruction

#### 1 General

YCB6H-63 miniature circuit breaker(circuitbreaker) is applicable to the circuit with AC50Hz/60Hz, rated voltage of no more than 400Rand rated current up to 63 A for overload protection and short circuit protection. This product can be applied to various places such as industrial, commercial, tall buildings, and residential houses.

Standard: IEC60898-1 2. Operating conditions

- 2.1 Ambient air temperature -25°C~+60°C
- 2 2 Altitude: <2000m
- 2.3 Air conditions At mounting the maximum humidity not exceed 50% at the maximum temperature of +40°C. For the wettest month, the maximum relative humidity averaged shall be 90% while the lowest temperature averaged in that month is +20°C,

special measures should be taken to occurrence of condensation

- 2.4 The installation category is II, III.
- 2.5 The circuit breaker shall be installed on DIN rail EN 60715 (35mm), which shall meet the A1.1 TH 35-7.5 steel mounting rail requirements.
- 2.6 Pollution grade: 2
- 2.7 Mounting conditions: inclination between mounting plane and vertical plane not exceed ±5°.

 $2.8\,\mbox{The}$  product should locate in the places where there are no obvious impact and shake.

## 3.1 Type designation



3.2 The basic specifications and main technical parameters of the circuit breaker are shown in Table 1; The overcurrent protection characteristics are shown in Table 2.

Table 1

Ui	Number of poles	Rated frequency Hz	Rated voltage Ue	Rated current In	Thermo- magnetic release characteristic	Rated short circuit breaking capacity Icn
500V	1P/2P	50/60	AC230V/ 400V	6A, 10A, 16A, 20A, 25A, 32A, 40A, 50A, 63A	B/C/D	6kA
	3P/4P		AC400V			

7	
Φ	
q	
ď	
_	

	Remarks	current	increase	steadily within 5s	Tum m on the power supply by closing the auxiliary switch	Tum on the power supply by closing the auxiliary switch	and at the
	Testing environment temperature	30°C∼35°C					tact is parfo
	Expected result	Not tripping	Tripping	Tripping	Not tripping	Tripping	att tett a
lable 2	Time limit for tripping or not tripping	t≤1h	t<1h	1s <t<60s (In ≤ 32A) 1s<t< 120s<br="">(In &gt; 32A)</t<></t<60s 	t≤0.1s	t<0.1s	ate,"mean
	Initial status	Cold state	Right after test number a	Cold state	Cold state	Cold state	Note: The terminology,"Cold state,"means that the test is performed at the
	Type Current	BCD 1.13ln	BCD 1.45ln	2.55In	3h 10h 10h	10lh 14lh	terming
	Туре	BCD	BCD	В	ВСО	воо	T P
	Test	а	q	O	р	Φ	Note

Note: The terminology"Cold state means that the test is performed at the base calibration temperature with no load prior to the test.

# 3.3 Mechanical and Electrical life shown in Table 3 Table 3

Item Times		Operation Frequency times/h	Rated current(A)
Electrical	6000	240	1~32
life		120	40~3
Mechanical life	20000	240	1~63


#### 3.4 Wire connection

Before installation, check whether technical parameter of the circuit breaker is in conformity with user's requirement. The conductor of power supply shall be connected to the up terminal of circuit breaker. During installation, the tightening torque is max 2.5N·m. The sectional area of connecting wire can refer to Table 4.

Table 4

Rated current In A	Conductor cross section S mm <sup>2</sup>		
6	1		
10	1.5		
16, 20	2.5		
25	4		
32	6		
40, 50	10		
63	16		

## 4 Overall and mounting dimensions



## 5 Ordering instruction

5.1 When ordering, the customer shall indicate the product type, tripping curve, rated current, number of poles, accessories and quantity of the circuit breaker. For example: YCB6H-63 C25 3P 880pcs. 5.2 Customers can negotiate separately if you have special requirements.



# CERTIFICATE

Product Model: YCB6H-63 Standard: IEC 60898-1

Inspector : CNC001

Production date: Printed on the product or package.

This product is qualified according to the delivery inspection

### **CNC ELECTRIC**

Tel: 0086-577-61989999 Fax: 0086-577-61891122 www.cncele.com E-mail: cncele@cncele.com