
Table 4

Rated current In A	conductor cross section S mm <sup>2</sup>
6	1
10	1.5
16、20	2. 5
25	4
32	6

4 Overall and mounting dimensions



-06-

5 Ordering instruction

5.1 When ordering, the customer shall indicate the product type, tripping curve, rated current, number of poles, accessories and quantity of the circuit breaker. For example: YCB6N-32 C25 880pcs.

5.2 Customers can negotiate separately if you have special requirements.

-07-

Product Model: YCB6N-32
Standard: IEC 60898-1
Inspector: CNC.001
Production date: Printed on the product or package.
This product is qualified according to the delivery inspection

YCB6N-32 Miniature Circuit Breaker OPERATION INSTRUCTION Standard: IEC 60898-1

Deliver
Power For Better Life

Before installing and using this product, please read this manual carefully and pay more attention to safety.

## **CNC ELECTRIC**

Tel: 0086-577-61989999 Fax: 0086-577-61891122 www.cncele.com E-mail: cncele@cncele.com

YCB6N series Miniature Circuit Breaker Instruction

## General

YCB6N-32 miniature circuit breaker(circuit breaker) is applicable to the circuit with AC 50Hz/60Hz, rated voltage up to 230V,and rated current up to 32A for overload protection and short circuit protection. This product can be applied to various places such as industrial, commercial, tall buildings, and residential houses.

Standard: IEC60898-1


- 2. Operating conditions
- 2.1 Ambient air temperature -5 °C ~+40 °C
- 2.2 Altitude: ≤2000m.

-01-

- 2.3 Air conditions: At mounting site, relative humidity not exceed 50% at the maximum temperature of +40°C. For the wettest month, the maximum relative humidity averaged shall be 90% while the lowest temperature averaged in that month is +20°C, special measures should be taken to occurrence of condensation.
- 2.4 The installation category is II, III.
- 2.5 The circuit breaker shall be installed on DIN rail EN 60715 (35mm), which shall meet the A1.1 TH 35-7.5 steel mounting rail requirements.
- 2.6 Pollution grade: 2
- 2.7 Mounting conditions: inclination between mounting plane and vertical plane not exceed ±5°.

2.8 The product should locate in the places where there are no obvious impact and shake.

3.1 Type designation



3.2 The basic specifications and main technical parameters of the circuit breaker are shown in Table 1; The overcurrent protection characteristics are shown in Table 2.

Table 1

Ui	Number of poles	Rated frequency Hz	Rated voltage Ue	Rated Current In	Thermo-magnetic release characteristic	Rated short circuit breaking capacity Icn
500V	1P+N(1P with protection)	50/60	AC230V	6A,10A,16A 20A,25A,32A	B,C type	3kA

-03-

	-	Test		IIIII aliiii		icsillig		
sst	Type	ourrant	Initial status	for tripping	Expected result environment	environment	Remarks	
		III AIII A		or not tripping		temperature		
	B,C	UE 1.1	cold state	t≤lh	Not tripping			
	B,C	1.45In	Right after test number a	t(Ih	Tripping		current increase	
1	B,C	2.55In	cold state	1s(1(60s (In≤32A)	Tripping	300~350	steadily within 5s	
	В	uIS uIE	cold state	t≤0.1s	Not tripping	200	Tum on the power supply by closing the auxiliary switch	
1	B	5In 10In	cold state	t<0.1s	Tripping		Tum on the power supply by closing the auxiliary switch	
≠ :=	e: The	terminolc	gy "Cold st	tote: The terminology "Cold state" means that the test is performed at the base althration temperature with no load prior to the test	at the test is	performe	ed at the base	
í				and been a				

-04-

3.4 Wire connection

Item

Electrical life

Mechanical life

Times

4000

10000

Before installation, check whether technical parameter of the circuit breaker is in conformity with user's requirement. The conductor of power supply shall be connected to the up terminal of

3.3 Mechanical and Electrical life shown in Table 3
Table 3

240

Oneration Frequency times/h Rated current(A)

torque is max 2N•m. The sectional area of

connecting wire can refer to Table 4.

-05-

circuit breaker. During installation, the tightening

-02-